

AEROVENT AUSTRALIA:

Premier Fan Engineering & Manufacture


Wiring Diagram — WD1-05

For External Rotor Motor Type

Single phase four speed motor with internal capacitor and internal thermal contact

Motor cable colour code:

1 = White 2 = Red 3 = Grey 4 = Black 5 = Blue (neutral)



Incoming 240V active connects to terminals 1 thru 4 depending on speed required.

1 = Lowest Speed

4 = Highest speed

Note:

- Internal thermal overheat protection contacts will reset and fan will re-start when temperature reduces after overload.
- When changing speeds, switch must break the circuit completely between speeds

www.aerovent.com.au