

Wiring Diagram — WD1-10

For Ex"d" Flameproof motor

1. Single phase flameproof motor is designed and produced in accordance with AS/NZS(IEC)60079.0 and 60079.1.
2. Rotation may be changed by interchanging leads 4 and 5 ONLY as shown below.
3. The green wire is Earth.
4. Motor is not to be disassembled by user. If there are any faults, refer to Aerovent.

