

## Wiring Diagram — WD1-11

### For Ex"d" Flameproof motor

1. **Single phase flameproof motor is designed and produced in accordance with AS/NZS(IEC)60079.0 and 60079.1.**
2. **Rotation is counter-clockwise viewed from shaft end and cannot be reversed.**
3. **The green wire is Earth; other wires are power lines.**
4. **Motor is not to be disassembled by user. If there are any faults, refer to Aerovent.**

