AEROVENT AUSTRALIA:

Premier Fan Engineering & Manufacture

Wiring Diagram — WD1-07

For External Rotor Motor Type

Single phase three speed motor with internal capacitor



Incoming 240V active connects to terminals 1 thru 3 depending on speed required.
1 = Lowest speed
2 = Medium speed
3 = Highest speed

Note: When changing speeds, switch must break the circuit completely between speeds

Due to Aerovent Australia's constant product improvement and development program, product details may change without prior notice.